

USER MANUAL

K80

CUSTOM[®]

CUSTOM S.p.A.
Via Berettine 2/B
43010 Fontevivo (PARMA) - Italy
Tel. : +39 0521-680111
Fax : +39 0521-610701
http: www.custom.biz

Customer Service Department:
www.custom4u.it

© 2018 CUSTOM S.p.A. – Italy.
All rights reserved. Total or partial reproduction of this manual in whatever form, whether by printed or electronic means, is forbidden. While guaranteeing that the information contained in it has been carefully checked, CUSTOM S.p.A. and other entities utilized in the realization of this manual bear no responsibility for how the manual is used. Information regarding any errors found in it or suggestions on how it could be improved are appreciated. Since products are subject to continuous check and improvement, CUSTOM S.p.A. reserves the right to make changes in information contained in this manual without prior notification.

The pre-installed multimedia contents are protected from Copyright CUSTOM S.p.A. Other company and product names mentioned herein may be trademarks of their respective companies. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. CUSTOM S.p.A. assumes no responsibility with regard to the performance or use of these products.

THE IMAGES USED IN THIS MANUAL ARE USED AS AN ILLUSTRATIVE EXAMPLES. THEY COULDN'T REPRODUCE THE DESCRIBED MODEL FAITHFULLY.

UNLESS OTHERWISE SPECIFIED, THE INFORMATION GIVEN IN THIS MANUAL ARE REFERRED TO ALL MODELS IN PRODUCTION AT THE ISSUE DATE OF THIS DOCUMENT.

GENERAL INSTRUCTIONS

CUSTOM S.p.A. declines all responsibility for accidents or damage to persons or property occurring as a result of tampering, structural or functional modifications, unsuitable or incorrect installations, environments not in keeping with the equipment's protection degree or with the required temperature and humidity conditions, failure to carry out maintenance and periodical inspections and poor repair work.

GENERAL SAFETY INFORMATION

Your attention is drawn to the following actions that could compromise the characteristics of the product:

- Read and retain the instructions which follow.
- Follow all indications and instructions given on the device.
- Make sure that the surface on which the device rests is stable. If it is not, the device could fall, seriously damaging it.
- Make sure that the device rests on a hard (non-padded) surface and that there is sufficient ventilation.
- Do not fix indissolubly the device or its accessories such as power supplies unless specifically provided in this manual.
- When positioning the device, make sure cables do not get damaged.
- [Only OEM equipment] The equipment must be installed in a kiosk or system that provides mechanical, electrical and fire protection.
- The mains power supply must comply with the rules in force in the Country where you intend to install the equipment.
- Make sure that there is an easily-accessible outlet with a capacity of no less than 10A closely to where the device is to be installed.
- Make sure the power cable provided with the appliance, or that you intend to use is suitable with the wall socket available in the system.
- Make sure the electrical system that supplies power to the device is equipped with a ground wire and is protected by a differential switch.
- Before any type of work is done on the machine, disconnect the power supply.
- Use the type of electrical power supply indicated on the device label.
- These devices are intended to be powered by a separately certified power module having an SELV, non-energy hazardous output. (IEC60950-1 second edition).
- [Only POS equipment] The energy to the equipment must be provided by power supply approved by CUSTOM S.p.A.
- Take care the operating temperature range of equipment and its ancillary components.
- Do not block the ventilation openings.
- Do not insert objects inside the device as this could cause short-circuiting or damage components that could jeopardize printer functioning.
- Do not carry out repairs on the device yourself, except for the normal maintenance operations given in the user manual.
- The equipment must be accessible on these components only to trained, authorized personnel.
- Periodically perform scheduled maintenance on the device to avoid dirt build-up that could compromise the correct, safe operation of the unit.
- Do not touch the head heating line with bare hands or metal objects. Do not perform any operation inside the printer immediately after printing because the head and motor tend to become very hot.
- Use consumables approved by CUSTOM S.p.A.



THE CE MARK AFFIXED TO THE PRODUCT CERTIFY THAT THE PRODUCT SATISFIES THE BASIC SAFETY REQUIREMENTS.

The device is in conformity with the essential Electromagnetic Compatibility and Electric Safety requirements laid down in Directives 2014/30/EU and 2014/35/EU inasmuch as it was designed in conformity with the provisions laid down in the following Standards:

- EN 55032 (*Limits and methods of measurements of radio disturbance characteristics of Information Technology Equipment*)
- EN 55024 (*Information Technology Equipment – Immunity characteristics – Limits and methods of measurement*)
- EN 60950-1 (*Safety of information equipment including electrical business equipment*)

The device is in conformity with the essential requirements laid down in Directives 2014/53/EU about devices equipped with intentional radiators. The Declaration of Conformity and other available certifications can be downloaded from the site www.custom4u.it.




GUIDELINES FOR THE DISPOSAL OF THE PRODUCT

The crossed-out rubbish bin logo means that used electrical and electronic products shall NOT be mixed with unsorted municipal waste. For more detailed information about recycling of this product, refer to the instructions of your country for the disposal of these products.

- Do not dispose of this equipment as miscellaneous solid municipal waste, but arrange to have it collected separately.
- The re-use or correct recycling of the electronic and electrical equipment (EEE) is important in order to protect the environment and the wellbeing of humans.
- In accordance with European Directive WEEE 2002/96/EC, special collection points are available to which to deliver waste electrical and electronic equipment and the equipment can also be handed over to a distributor at the moment of purchasing a new equivalent type.
- The public administration and producers of electrical and electronic equipment are involved in facilitating the processes of the re-use and recovery of waste electrical and electronic equipment through the organisation of collection activities and the use of appropriate planning arrangements.
- Unauthorised disposal of waste electrical and electronic equipment is punishable by law with the appropriate penalties.



The format used for this manual improves use of natural resources reducing the quantity of necessary paper to print this copy.



For details on the commands,
refer to the manual with code **77200000003300**



TABLE OF CONTENTS

1	INTRODUCTION	9
2	DESCRIPTION	11
2.1	Box contents	11
2.2	Device components: external views	12
2.3	Product label	15
2.4	Key functions: power up	16
2.5	Key functions: standby	17
2.6	Status messages	18
3	INSTALLATION	19
3.1	Fastening	19
3.2	Connections	21
3.3	Pinout	22
3.4	Driver and SDK	24
4	OPERATION	25
4.1	Switch the device on	25
4.2	Adjusting paper width	26
4.3	Loading the paper roll	27
4.4	Anti-jamming system	28
4.5	Shutter for outdoor	29
5	CONFIGURATION	31
5.1	Configuration mode	31
5.2	Setup report	32
5.3	Device status	33
5.4	Printer parameters	34
5.5	Hexadecimal dump	39
6	MAINTENANCE	41
6.1	Printer paper jam	41
6.2	Planning of cleaning operations	43
6.3	Cleaning	44
6.4	Upgrade firmware	47




7	SPECIFICATION	49
7.1	Hardware specifications	49
7.2	Character specifications	52
7.3	Device dimensions	53
7.4	Power supply dimensions	55
7.5	Paper specification (only with black mark sensor kit)	56
7.6	Character sets	58
8	CONSUMABLES	61
9	ACCESSORIES	63
10	ALIGNMENT	65
10.1	Enable alignment	65
10.2	Calibration	67
10.3	Alignment parameters	69
10.4	Printing area	72
11	TECHNICAL SERVICE	73



1 INTRODUCTION

This document is divided into sections and chapters. Each chapter can be reached by the index at the beginning of this document. The index can be reached by the button on each page as shown in the diagram below.








2 DESCRIPTION

2.1 Box contents

Remove all the box contents (see following figures) being careful not to damage the packing material so that it may be re-used if the device is to be transported in the future.

Make sure that all the components illustrated below are present and that there are no signs of damage. If there are, contact Customer Service.

1. Device
2. Locking ring
3. Installation instructions






2.2 Device components: external views

Model A


- | | | |
|---|-------------------------------------|--|
| 1. Black mark sensor (Optional - adjustable in position A, B, C, D, E or F) | 7. RS232 serial port | 15. Sensor for paper presence |
| 2. Status LED | 8. Low paper sensor | 16. Printing mechanism motor |
| 3. LF LINE FEED key | 9. Roll holder pin 60/80 mm | 17. Device chassis |
| 4. ON/OFF key | 10. Ring for roll blocking | 18. Printing mechanism + head temperature sensor |
| 5. Power supply port | 11. Paper input | 19. Unlocking lever for platen roller |
| 6. USB port | 12. Autocutter | 20. Platen roller manual feed |
| | 13. Ticket out and paper jam sensor | |
| | 14. Paper out | |





Model A with black mark sensor


- | | | |
|----------------------|-------------------------------------|--|
| 1. Black mark sensor | 9. Roll holder pin 60/80 mm | 17. Device chassis |
| 2. Status LED | 10. Ring for roll blocking | 18. Printing mechanism + head temperature sensor |
| 3. LF LINE FEED key | 11. Paper input | 19. Unlocking lever for platen roller |
| 4. ON/OFF key | 12. Autocutter | 20. Platen roller manual feed |
| 5. Power supply port | 13. Ticket out and paper jam sensor | |
| 6. USB port | 14. Paper out | |
| 7. RS232 serial port | 15. Sensor for paper presence | |
| 8. Low paper sensor | 16. Printing mechanism motor | |





Model B


- | | | |
|---|-------------------------------|--|
| 1. Black mark sensor (Optional - adjustable in position A, B, C, D, E or F) | 7. RS232 serial port | 15. Printing mechanism motor |
| 2. Status LED | 8. Low paper sensor | 16. Device chassis |
| 3. LF LINE FEED key | 9. Roll holder pin 60/80 mm | 17. Printing mechanism + head temperature sensor |
| 4. ON/OFF key | 10. Ring for roll blocking | 18. Unlocking lever for platen roller |
| 5. Power supply port | 11. Paper input | 19. Platen roller manual feed |
| 6. USB port | 12. Autocutter | |
| | 13. Paper out | |
| | 14. Sensor for paper presence | |






2.3 Product label

PC = Product code (14 digits)
SN = Serial number
HW = Hardware release






2.4 Key functions: power up



2.5 Key functions: standby





2.6 Status messages

The status LED indicates hardware status of device. Given in the table below are the various LED signals and the corresponding device status.

STATUS LED		DESCRIPTION	
-		OFF	DEVICE OFF
GREEN		ON	DEVICE ON: NO ERROR
GREEN		x 1	RECEIVE DATA
		x 2	PRINthead OVERHEATED
		x 3	PAPER END
		x 4	POWER SUPPLY VOLTAGE INCORRECT
		x 5	RECEPTION ERRORS (PARITY, FRAME ERROR, OVERRUN ERROR)
		x 6	COMMAND NOT RECOGNIZED
		x 7	COMMAND RECEPTION TIME OUT
		x 8	COVER OPEN
		x 9	PAPER JAM
		x 10	CUTTER ERROR
		x 11	RAM ERROR
		x 12	EXTERNAL FLASH MEMORY ERROR


3 INSTALLATION

3.1 Fastening

The device is provided with three fixing holes on the bottom of device (see following figures). To install the device on a panel, use three M4 screws.


NOTE: All the dimensions shown in following figures are in millimetres.

Model A, Model A with black mark sensor






Model B





3.2 Connections

The following figure shows the possible connections for the device.



ATTENTION: In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

NOTE: When the RS232 and USB communication cables are connected to the device at the same time, communication takes place via the USB port.

3.3 Pinout



POWER SUPPLY

Male Molex connector series 5569 vertical (n° 39-30-1020)


J11	1	+24 Vdc
	2	GND

ATTENTION:

Respect power supply polarity.


NOTE: Power supply cable

The following figure shows the connector pinout of the power supply cable for the device:



Female Molex connector series 5557 (n° 39-01-3022)


PIN	Cable color	Signal
1	Red	+24 V
2	Black	GND



USB INTERFACE

Female USB type B connector

J2	1	USB0-VBUS	(in)
	2	USB0_D-	(in/out)
	3	USB0_D+	(in/out)
	4	GND	
	SH1	SHIELD	
	SH2	SHIELD	



RS232 SERIAL INTERFACE

Female DB9 connector


J1	1	DCD	
	2	TX	During transmission, takes the values -VRS232 and +VRS232 depending on data
	3	RX	During reception, takes the values -VRS232 and +VRS232 depending on data
	4	DSR	
	5	GND	
	6	DTR	When +VRS232, device is power on
	7	CTS	
	8	RTS	When +VRS232, device is ready to receive data
	9	VCC	

NOTES:

Given the presence of the RS232 standard, logic value "0" corresponds to the voltage value +VRS232 (voltage value between +3 Vdc and +15 Vdc) and logic value "1" corresponds to the voltage value -VRS232 (voltage value between -3 Vdc and -15 Vdc).

DEVICE > PC connection

The following picture shows an example of connection between the device and a personal computer using a 9 pin RS232 serial connector:



When use a serial cable, we recommend the installation of a ferrite core on the power supply cable.



3.4 Driver and SDK

The drivers are available for the following operating system:

OPERATING SYSTEM	DESCRIPTION	INSTALLATION PROCEDURE
Windows	Driver for Windows XP	From the Start menu, press Run and type-in the path where the SW was saved on your PC, then click OK. Follow the instructions that appear on the screen to install the driver.
	Driver for Windows VISTA (32/64 bit)	
	Driver for Windows 7 (32/64 bit)	
	Driver for Windows 8 (32/64 bit)	
	Driver for Windows 8.1 (32/64 bit)	
	Driver for Windows 10 (32/64 bit)	
Linux	(32/64 bit)	Follow the instruction get back on the "Readme.txt" file. You can find it in the software package downloaded in advance.
Android	Library for CustomAndroidAPI	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the library.
iOS	Library for CustomiOSApi	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the library.


NOTE:

All drivers can be found in the web site www.custom4u.it.




4 OPERATION

4.1 Switch the device on



Connect the power supply cable to an external power supply unit (optional) and to the device. Use the type of electrical power supply indicated on the label.




Switch device on by pressing the ON/OFF key.

4.2 Adjusting paper width

The paper width may be set to 76 mm or 80 mm by assembling the adjustment ring to ensure the right paper alignment inside the device (see the following figure).

ATTENTION:


** Requires the 76 mm paper guide (see [chapter 9](#)).



4.3 Loading the paper roll


To load the paper proceed as follows. At every change of paper, check inside the device to locate and remove any scraps of paper.

1



Assemble the ring as described in the previous paragraph.

2




Insert the paper roll on the pin so that it unrolls correctly.

3



Insert the paper into the input mouth.

4



Wait until the paper is automatically loaded and cut.




4.4 Anti-jamming system

Model A (as standard), Model B (optional)


The anti-jamming system starts operating when the user tries to block the paper output while printing is still in progress. This system is composed of an infrared reflex sensor that detects the lifting of the paper. The user that blocks the paper bezel before the printing end, causes the lifting of the paper inside the device. This movement disengages the reflex sensor: printing is interrupted until the paper bezel is not unblocked.

1



The device starts the ticket printing.

2




During the printing of the ticket, the obstruction of the paper bezel causes lifting of the paper inside the printer. The sensor is disengaged generating the status of 'paper jam'.

ATTENTION: To work properly, the non-thermal side of the paper must be completely white.


4.5 Shutter for outdoor

Model A


The shutter, prevents the accidental introduction of objects in the device bezel allowing to reduce the onsite technical assistance costs, because it significantly increases the life of the internal components. The system works as described below:



3



The user withdraws the ticket from the paper bezel.
The shutter is no longer supported by the passage of the paper and is lowered.



Any attempt to insert a foreign object from the paper bezel
is prevented by the shutter lowered


5 CONFIGURATION

5.1 Configuration mode

To enter the configuration mode and print a setup report with the operating parameters of the device, proceed as follows.


1

LF LINE FEED
KEY




+

ON/OFF
KEY



While pressing the LF LINE FEED key,
switch on the device by pressing the ON/OFF key.

2



The device prints the report with the settings parameters.
Follow the instruction printed on paper to proceed with configuration procedure.



5.2 Setup report

The following figure shows the setup report of the device. The shown values for parameters are sample values; for the list and the description of device parameters see the following paragraphs.

PRINTER NAME AND FIRMWARE MODULES RELEASE	}	<pre> <device name> SCODE. <code> - rel 1.00 FCODE. <code> - rel 1.00 </pre>
DEVICE STATUS	}	<h3>PRINTER SETTINGS</h3> <pre> PRINTER TYPE<device model> PRINTING HEAD TYPE<head model> INTERFACEUSB PROGRAM MEMORY TEST.....OK CUTTER TEST.....OK HEAD VOLTAGE [V] = 24.12 HEAD TEMPERATURE [°C] = 24 POWER ON COUNTER = 4 PAPER PRINTED [cm] = 40 CUT COUNTER = 1 </pre>
PRINTER PARAMETERS	}	<pre> RS232 Baud Rate: 115200 bps RS232 Data Length.....: 8 bits/chr RS232 Parity: None RS232 Handshaking: Hardware Busy Condition: RxFull USB Address Number: 0 Print Mode: Normal Autofeed: CR Disabled Chars / inch: A=17 B=22 cpi Code Table [num]: 00 Font Type.....: International Speed / Quality.....: Normal Print Width: 76 mm B.Mark Position: Enabled B.Mark Threshold: 40% B.Mark Distance [mm]: +00.0 PaperEnd Buffer Clear: Disabled Antijam Function.....: Enabled T.out Filter [mm].....: 08 Printer SetUp Key.....: Enabled Page to Page function: Disabled Print Density.....: 0% </pre>
KEYS FUNCTIONS	}	<pre> [PUSH] to enter setup [FAST PUSH] to skip setup </pre>



5.3 Device status

The device operating status is indicated in the configuration print-out in which, next to the name of the components displayed, the following information is given:

PRINTER TYPE	device model
PRINTING HEAD TYPE	print head model
INTERFACE	interface present
PROGRAM MEMORY TEST	OK appears if functioning and NOT OK if faulty
CUTTER TEST	OK appears if functioning and NOT OK if faulty
HEAD VOLTAGE	voltage of the head
HEAD TEMPERATURE	temperature of the head
POWER ON COUNTER	number of power-ups made
PAPER PRINTED	centimetres of paper printed
CUT COUNTER	number of cuts made



5.4 Printer parameters

The device allows the configuration of the parameters listed in the following table. The parameters marked with the symbol ^D are the default values. Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

RS232 BAUD RATE	Communication speed of the serial interface: 1200 4800 19200 57600 2400 9600 38400 115200 ^D
	NOTE: Parameter valid only with serial interface.
RS232 DATA LENGTH	Number of bit used for characters encoding: 8 bits/car ^D 7 bits/car
	NOTE: Parameter valid only with serial interface.
RS232 PARITY	Bit for the parity control of the serial interface: None ^D = parity bit omitted Even = even value for parity bit Odd = odd value for parity bit
	NOTE: Parameter valid only with serial interface.
RS232 HANDSHAKING	Handshaking: XON/XOFF = software handshaking Hardware ^D = hardware handshaking (CTS/RTS)
	NOTES: Parameter valid only with serial interface. When the receive buffer is full, if handshaking is set to XON/XOFF, the device sends the XOFF (0x13) on the serial port. When the receive buffer has cleared once again, if handshaking is set to XON/XOFF, the device sends the XON (0x11) on the serial port.
BUSY CONDITION	Activation mode for Busy signal: RXFull ^D = Busy signal is activated when the buffer is full OffLine/ RXFull = Busy signal is activated when the device is both in OffLine status and the buffer is full
	NOTE: Parameter valid only with serial interface.
USB ADDRESS NUMBER	Numerical address code for the univocal identification of the USB device (in case of more than a USB device connected with the same PC): 0 ^D 2 4 6 8 1 3 5 7 9



PRINT MODE Printing mode:

Normal ^D = enables printing in normal writing way
 Reverse = enables printing rotated 180 degrees

AUTOFEED Setting of the Carriage Return character:

CR disabled ^D = Carriage Return disabled
 CR enabled = Carriage Return enabled

CHARS / INCH Font selection:

A = 17 cpi, B = 22 cpi ^D
 A = 13 cpi, B = 17 cpi

NOTE:
 CPI = Characters Per Inch.

CODE TABLE [num] Identifier number of the character code table to use.
 The numeric value of the identifier is made up with the following two parameters for the setting of two digits for the tens and the units:

Setting the digit for tens:

CODE TABLE [num x 10]	0 ^D	2	4
	1	3	5

Setting the digit for units:

CODE TABLE [num x 1]	0 ^D	2	4	6	8
	1	3	5	7	9

NOTE: The character tables set with this parameter are the same set with the command 0x1B 0x74 (refer to the commands manual of the device).

FONT TYPE Setting of the font type:

International ^D = Enables the use of the 256 characters font tables
 Chinese GB18030 = Enables the use of the chinese extended font GB18030-2000
 Korean CP949 = Enables the use of the korean font CP949

NOTE: When the "International" font is enabled, you need to choose the character code table (parameter "Code table"). When the Chinese or Korean fonts is enabled, the selection of the character code table is suspended (parameter "Code table").

SPEED / QUALITY Setting of printing speed and printing quality:

High Speed
 Normal ^D
 High Quality



PRINT WIDTH

Printing area width:

52 mm	58 mm	64 mm	70 mm	76 mm ^D
54 mm	60 mm	66 mm	72 mm	78 mm
56 mm	62 mm	68 mm	74 mm	80 mm

BLACK MARK POSITION

Position of the alignment black mark and choice of appropriate black mark sensor:

Disabled^D = the black mark alignment is not performed

Enabled = the black mark alignment is performed

BLACK MARK THRESHOLD

Threshold value (in percent) for the recognition of the presence of black mark by the black mark sensor:

30%	70%
40% ^D	80%
50%	90%
60%	

NOTE: If the "Black mark position" parameter is disabled, this parameter is not printed.



BLACK MARK DISTANCE

“Black mark distance” is the minimum distance (in millimeters) between the upper edge of ticket and the black mark.

The numeric value of the distance is made up with the following four parameters for the setting of three digits (two for the integer part of the number, one for the decimal part) and of the sign:

	Sign setting:				
BLACK MARK DISTANCE SIGN	+ ^D	=	positive distance		
	-	=	negative distance		
	Setting the digit for tens:				
BLACK MARK DISTANCE [mm x 10]	0 ^D	2	4	6	8
	1	3	5	7	9
	Setting the digit for units:				
BLACK MARK DISTANCE [mm x 1]	0 ^D	2	4	6	8
	1	3	5	7	9
	Setting the digit for decimals:				
BLACK MARK DISTANCE [mm x .1]	0 ^D	2	4	6	8
	1	3	5	7	9

NOTES:

For example, to set the black mark distance to 15 mm, modify the parameters as follows:

Black mark distance sign	= +
Black mark distance [mm x 10]	= 1
Black mark distance [mm x 1]	= 5
Black mark distance [mm x .1]	= 0

If the “Black mark position” parameter is disabled, the parameters for the “Black mark distance” are not printed.

PAPEREND BUFFER CLEAR

Cleaning mode of the data in receive buffer, if the printing is stopped due to lack of paper:

Disabled^D = The data remain in the receive buffer. When the paper runs out, the device keeps the remaining data in the receive buffer and prints the remaining portion of the ticket after that the new paper is loaded.

Enabled = When the paper runs out, all data in the receive buffer are deleted.

ANTI JAM FUNCTION

Setting the sensor for the detection of the paper jam:

Disabled = Sensor disabled

Enabled^D = Sensor enabled

NOTE: For Model B this parameter must always be set to “Disabled”.



TICKET OUT FILTER [mm] Setting the tolerance millimeters to avoid false paper jam messages in case of paper with back side pre-printed:

0 mm 2 mm 4 mm 6 mm 8 mm ^D 10 mm
1 mm 3 mm 5 mm 7 mm 9 mm

PRINTER SETUP KEY Setting the option to change the setup parameters at power up:

Disabled = Parameters can only be modified with "PrinterSet" tool
Enabled ^D = Parameters can be modified from setup and "PrinterSet" tool

PAGE TO PAGE FUNCTION Setting the device behavior after the ticket presentation:

Disabled ^D = the device prints the ticket even though the previous ticket has not been withdrawn
Enabled = the device prints the ticket only if the previous ticket has been withdrawn

PRINT DENSITY Adjusting the printing density:

-25%
-12%
0 ^D
+12%
+25%



5.5 Hexadecimal dump

This function is used for the diagnosis of the characters received from the communications port. Characters are printed as hexadecimal code and the corresponding ASCII code (see below). Each line is preceded by a counter in hexadecimal that indicates the number of bytes received.

During the startup, if you hold down the FEED key, the device enters the self-test routine and print the setup report. The device remains in standby until a key is pressed or characters are received through the communication port (hexadecimal dump mode). For each character sent, the ticket shows the hexadecimal value and the ASCII codes (if the characters are underlined, the receive buffer is full). Shown below is an example of a hexadecimal dump:


HEXADECIMAL DUMP									
31	32	33	34	35	...	12345	...		
39	30	31	32	33	...	90123	...		
37	38	39	75	69	...	789ui	...		
68	6B	6A	73	64	...	hkjsd	...		
73	64	66	6B	6A	...	sdfkj	...		
66	73	64	66	6B	...	fsdfk	...		
65	69	6F	79	75	...	eioyu	...		
6F	72	69	75	77	...	oriuw	...		
6F	75	77	65	72	...	ouwer	...		
77	65	72	69	6F	...	werio	...		
72	69	6F	75	77	...	riouw	...		
6B	6C	73	64	66	...	kl sdf	...		
64	66	6B	73	64	...	dfksd	...		
73	64	66	6B	6A	...	sdfkj	...		
66	6B	F2	6A	73	...	fk>j	...		
6A	6B	6C	68			jklh			



6 MAINTENANCE


6.1 Printer paper jam

1




Unlock the autocutter by using the lever.

2




Lift the autocutter to the maximum opening position.

3




Lift the unlocking lever for the platen roller and remove any scraps of paper from the printing mechanism.

4



Pull out the damaged paper from the autocutter.

5



Rotate counterclockwise the platen roller to eject the paper from the rear side of the device.



6.2 Planning of cleaning operations

The regular cleaning of the device keeps the print quality and extends its life. The following table shows the recommended planning for the cleaning operations.

EVERY PAPER CHANGE	
Rollers	Use isopropyl alcohol
EVERY 5 PAPER CHANGES	
Paper path	Use compressed air or tweezers
Autocutter	Use compressed air
Sensors	Use compressed air
Ejector	Use compressed air
EVERY 6 MONTHS OR AS NEEDED	
Case	Use compressed air or a soft cloth

For specific procedures, see the following pages.

NOTE:


If you use the device in dusty environments, you must reduce the intervals between the cleaning operations.

6.3 Cleaning

For periodic cleaning of the device, see the instructions below.


Rollers

1



Disconnect the power supply cable and open the device (see previous paragraphs).

2



ATTENTION:


Do not use solvents, or hard brushes.
Do not let water or other liquids get inside the machine.



Clean the platen roller by using a non-abrasive cloth moistened with isopropyl alcohol.


Paper path

1



Disconnect the power supply cable and open the device (see previous paragraphs).

2



ATTENTION:


Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.



Remove any scraps of paper and the accumulated paper dust on the platen roller and in areas near to the paper presence sensor.


Autocutter

1



Disconnect the power supply cable and open the device (see previous paragraphs).

2




ATTENTION:
Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.



Remove any scraps of paper and the accumulated paper dust on the input and the output of autocutter.


Case

1



Disconnect the power supply cable (see previous paragraphs).

2




ATTENTION:
Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.



To clean the device, use compressed air or a soft cloth.


Ejector

1




Disconnect the power supply cable
(see previous paragraphs).

2



Lift and keep open
the inspection door.

3



ATTENTION:
Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the device.




Clean the sensor for paper jam
by using compressed air. Remove any scraps
of paper and the accumulated paper dust.

6.4 Upgrade firmware

Upgrade firmware can be performed by using the “PrinterSet” software tool.

The “PrinterSet” software tool and the latest firmware version of the device are available in the site www.custom4u.it.

To upgrade firmware, proceed as follows:



For further information about the use of “PrinterSet”, refer to the dedicated manual.

ATTENTION:

During communication between PC and printer for the firmware update it is strictly forbidden to disconnect the communication cable or to remove the power supply of the devices not to endanger the proper functioning of the printer. Only during the firmware update, the connection between PC and printer must be direct, without the use of wireless HUB.





7 SPECIFICATION

7.1 Hardware specifications

GENERAL	
Sensors	
Model A	Head temperature, paper presence, low paper, ticket out and paper jam, black mark (optional), external low paper (optional)
Model A with black mark sensor	Head temperature, paper presence, low paper, ticket out and paper jam, black mark, external low paper (optional)
Model B	Head temperature, paper presence, low paper, ticket out and paper jam (optional), black mark (optional), external low paper (optional)
Emulations	CUSTOM/POS
Printing driver	Windows XP VISTA (32/64 bit) Windows 7 (32/64 bit) Windows 8 (32/64 bit) Windows 8.1 (32/64 bit) Windows 10 (32/64 bit) Linux (32/64 bit) Android iOS
INTERFACES	
USB port	12 Mbit/s (USB 2.0 full speed)
RS232 serial port	from 1200 bps to 115200 bps
MEMORIES	
Receive buffer	8 kB
Flash memory	768 kB interna, 4 MB esterna
RAM memory	128 kB
Graphic memory	1 loghi da 640 x 409 dots



PRINTER

Resolution	203 dpi (8 dot/mm)
Printing method	Thermal, fixed head
Head life ⁽¹⁾	
Abrasion resistance ⁽²⁾	100 km (with recommended paper)
Pulse durability	100 M (12.5% duty cycle)
Printing width	from 52 mm to 80 mm (step di 2 mm)
Printing mode	Normal, 90°, 180°, 270°
Printing format	Height/Width from 1 to 8, bold, reverse, underlined, italic
Character fonts	54 character code tables Extended chinese GB18030-2000, Korean PC949
Printable barcode	UPCA, UPCE, EAN13, EAN8, CODE39, ITF, CODABAR, CODE93, CODE128, CODE32, QRCODE
Printing speed ^{(1) (3)}	High speed = 150 mm/s Normal = 130 mm/s High quality = 100 mm/s

PAPER

Type of paper	Thermal rolls, heat-sensitive side on outside of roll
Paper width	76 mm, 80 mm ± 0.5 mm
Paper weight	from 55 g/m ² to 80 g/m ²
Paper thickness	from 63 µm to 88 µm
Recommended types of paper	KANZAN KF50 e KP460 MITSUBISHI PF5067 e TL4000
Minimum ticket length	70 mm
Maximum ticket length	300 mm
External roll diameter ⁽⁴⁾	max 180 mm
External roll core diameter	25 mm (+ 1 mm)



Paper end	Not attached to roll core
Core type	Cardboard or plastic
AUTOCUTTER	
Paper cut	Total or partial
Estimated life ⁽¹⁾	1000000 cuts
DEVICE ELECTRICAL SPECIFICATIONS	
Power supply	24 Vdc ± 10% (optional external power supply)
Medium consumption ⁽⁵⁾	2.2 A
Typical consumption ⁽³⁾	0.8 A
Standby consumption	0.04 A
ELECTRICAL SPECIFICATIONS POWER SUPPLY cod.963GE020000046 (OPTIONAL)	
Power supply voltage	da 100 Vac a 240 Vac
Frequency	da 50 Hz a 60 Hz
Output	24 V, 2.5 A
Power	60 W
ENVIRONMENTAL CONDITIONS	
Operating temperature	from 0°C to +50°C
Relative humidity	from 10% Rh to 85% Rh (w/o condensation)
Storage temperature	from -40 °C to +70 °C
Storage relative humidity	from 10% Rh to 90% Rh (w/o condensation)

NOTES:

- (1) : Respecting the regular schedule of cleaning for the device components.
- (2) : Damages caused by scratches, ESD and electromigration are excluded.
- (3) : Referred to a standard CUSTOM receipt (L = 10 cm, density = 12.5% dots on).
- (4) : For external rolls diameter higher to Ø 100 mm it's recommended to use a paper pretensioning device.
- (5) : Referred to the UL measurements (Print density = +50%, Ticket = 50% dots on, 1 ticket every 30 s).




7.2 Character specifications

Character set		3	
Character density	13 cpi	17 cpi	22 cpi
Number of columns	42	53	71
Chars / s	1200	2650	3550
Lines / s	50	50	50
Characters (L x H mm)-Normal	1.875 x 3	1.5 x 3	1.125 x 3

NOTE: Theoretical values.



7.3 Device dimensions

Model A, Model A with black mark sensor




Length	258 mm
Height	103.5 mm
Width	135 mm
Weight	1250 g

NOTE: All the dimensions shown in following figures are in millimetres.







Model B



Length	239.5 mm
Height	103.5 mm
Width	135 mm
Weight	1220 g


NOTE: All the dimensions shown in following figures are in millimetres.



7.4 Power supply dimensions cod. 963GE02000046 (optional)

Length	127 mm
Height	35.5 mm
Width	56 mm

NOTE: All the dimensions shown in following figures are in millimetres.




Paper with black mark on the non-thermal side

The following image shows the placement of the black mark on the non-thermal side of the paper. For more information about the use of paper with black mark see [chapter 10](#).

ATTENTION: Requires the assembly of the black mark sensor kit (optional, see [chapter 9](#)).

NOTE: All the dimensions shown in following figures are in millimetres.





7.6 Character sets

The device has 3 fonts of varying width (13, 17 and 22 cpi) which may be related one of the coding tables provided on the device.

To know the coding tables actually present on the device, you need to print the font test (see [paragraph 2.4](#)).

You can set font and coding table by using the commands (see the commands manual of the device) or using the "Code Table", "Chars / Inch" and "Font Type" parameters during the setup procedure (see [paragraph 5.4](#)).

The following is the full list of coding tables that can be installed on the device.

<CodeTable>	Coding table	
0	PC437 - U.S.A., Standard Europe	
1	Katakana	
2	PC850 - Multilingual	
3	PC860 - Portuguese	
4	PC863 - Canadian/French	
5	PC865 - Nordic	
11	PC851 - Greek	on request
12	PC853 - Turkish	on request
13	PC857 - Turkish	on request
14	PC737 - Greek	on request
15	ISO8859-7 - Greek	on request
16	WPC1252	
17	PC866 - Cyrillic 2	
18	PC852 - Latin 2	on request
19	PC858 per simbolo Euro in posizione 213	
20	KU42 - Thai	on request
21	TIS11 - Thai	on request
26	TIS18 - Thai	on request
30	TCVN_3 - Vietnamese	on request
31	TCVN_3 - Vietnamese	on request
32	PC720 - Arabic	on request




<CodeTable>	Coding table	
33	WPC775 - Baltic Rim	on request
34	PC855 - Cyrillic	on request
35	PC861 - Icelandic	on request
36	PC862 - Hebrew	
37	PC864 - Arabic	
38	PC869 - Greek	on request
39	ISO8859-2 - Latin 2	on request
40	ISO8859-15 - Latin 9	on request
41	PC1098 - Farci	on request
42	PC1118 - Lithuanian	on request
43	PC1119 - Lithuanian	on request
44	PC1125 - Ukrainian	on request
45	WPC1250 - Latin 2	
46	WPC1251 - Cyrillic	
47	WPC1253 - Greek	
48	WPC1254 - Turkish	
49	WPC1255 - Hebrew	
50	WPC1256 - Arabic	
51	WPC1257 - Baltic Rim	
52	WPC1258 - Vietnamese	
53	KZ1048 - Kazakhstan	on request
255	Space page	



8 CONSUMABLES





The following table shows the list of available consumables for devices:

DESCRIPTION	CODE
<p>THERMAL PAPER ROLL</p> <p>width = 80 mm Ø external = 90 mm Ø core = 25 mm</p>	<p>67300000000406</p> 



9 ACCESSORIES


The following table shows the list of available accessories for device:

DESCRIPTION	CODE
<p>POWER SUPPLY (for technical specifications, see paragraph 7.1)</p>	<p>963GE020000046</p> 
<p>ADAPTER CABLE FOR POWER SUPPLY</p>	<p>26900000000005</p> 
<p>EXTERNAL LOW PAPER SENSOR KIT board with cable 450 mm long</p>	<p>976LC010000002</p> 
<p>BLACK MARK SENSOR KIT board with cable</p>	<p>976LC010000003</p> 
<p>PAPER GUIDE KIT For paper width 76 mm</p>	<p>976LC010000004</p> 



976LC010000005

TICKET OUT SENSOR KIT
board with cable



10 ALIGNMENT


The device is provided with a sensor for the use of alignment black mark in order to handle rolls of tickets with pre-printed fields and a fixed length.

The alignment sensor is a “reflection” sensor: this kind of sensor emits a band of light and detects the quantity of light reflected to it. The presence of the black mark is therefore detected by the amount of light that returns to the sensor, considering that the light is reflected by the white paper and absorbed by the black mark.

The following paragraphs show how to correctly set the configuration parameters of device in order to assure the alignment.

10.1 Enable alignment


The device can detect the black mark on the paper only if equipped with the sensor (Model A with black mark sensor) or after mounting an optional sensor (see [chapter 9](#)). The sensor can be mounted in one of the six available positions.



To guarantee the correct alignment, you must enable the parameter “Black mark position” during the setup procedure (see [chapter 5](#)).



The following figure shows an example of paper with black mark usable with the device:



10.2 Calibration

The sensor calibration occurs automatically and consists in adjusting the quantity of light emitted to match the degree of whiteness of the paper used and the degree of black of the mark printed on paper.

The device automatically performs the self-calibration during the setup procedure only if the “Black mark position” parameter is set to a value other than “Disabled” (see [chapter 5](#)).


When self-calibration starts, the device performs some paper feeds and then it prints the calibration result and the value of the PWM duty-cycle of the alignment sensor driver so that it can be perform an optimal black mark detection:

```
Autosetting black mark : OK
PWM duty cycle : 85.3%
```


The “Autosetting black mark” parameter indicates the result of the self-calibration procedure; OK will appear if it has been successful, NOT OK will appear if the procedure has failed.

After the printing of the procedure result, the device offers the execution of the function of paper characterization “Characterize paper” and the change of the “Black mark threshold” parameter which represents the detection threshold of the black mark. Choosing the “Yes” value for the “Characterize paper” parameter, the device prints a graphic representation (see following figures) of the outgoing voltage of the alignment sensor (expressed as a percentage) and the “Black mark threshold” value. This graphic representation is useful to set the most suitable value to assign to the “Black mark threshold” parameter and then to better identify the optimal threshold value which takes into account the variations of the signal and the small oscillations around zero.

The following figure shows an example of paper with the non-thermal paper printed with black marks: the outgoing voltage is constant while passing the white paper between two black marks and presents a peak at each black mark. In this case, the optimal value for the “Black mark threshold” parameter is placed about half of the peak.



The following figure shows an example of paper with the non-thermal paper printed with black marks and other graphics (for example, a barcode): the outgoing voltage is constant while passing the white paper between two black marks, presents a peak at each black mark and presents some “noise” at each barcode. In this case, the optimal value for the “Black mark threshold” parameter is located about halfway between the peak value and the maximum value of the “noise”.




If the maximum value of “noise” read by the sensor is very close to the peak value, it might be difficult to place the value of the “Black mark Threshold” at an intermediate point. In these cases, it is mandatory that the portion of paper between the point of printing end and the front black mark is completely white (no graphics). In this way, the only next graphic detected by the sensor for alignment after the printing end will be the black mark.




10.3 Alignment parameters

The “alignment point” is defined as the position inside the ticket to use for the black mark alignment. The distance between the edge of the black mark and the alignment point is defined as “Black mark distance”.

Referring to the front of the black mark, the value of “Black mark distance” value varies from -90.0 mm minimum and 23.0 mm maximum. If the “Black mark distance” value is set to 0, the alignment point is set at the beginning of the black mark.




The following figure shows an example of paper with alignment point set by a positive value of “Black mark distance” (“Black mark distance” = + A):






To set a negative value of the “Black mark distance” parameter is useful in cases where the alignment point refers to the black mark printed on the previous ticket. In the following images, the value of “Black mark distance” parameter is set to -A.



The following figures show the simplified sections of the device models with the paper path and the distances (expressed in millimeters of theoretical paper path) between the alignment sensor, the printhead (printing line), cutter (cutting line).

Model A




A = distance between printhead and alignment sensor = 32.5 mm

B = distance between printhead and cutter = 10.5 mm

C = distance between cutter and paper outlet = 53.5 mm

Model B



A = distance between printhead and alignment sensor = 32.5 mm

B = distance between printhead and cutter = 10.5 mm

C = distance between cutter and paper outlet = 33.5 mm

To define the alignment point you need to set the device parameters that compose the numerical value of the “Black mark distance” parameter (see [paragraph 5.4](#)).

For example, to set a black mark distance of 15 mm between the black mark and the alignment point, the parameters must be set on the following values:

Black mark distance sign	:	+
Black mark distance [mm x 10]	:	1
Black mark distance [mm x 1]	:	5
Black mark distance [mm x .1]	:	0


The “Black mark distance” parameter, may be modified as follows:

- during the setup procedure of the device (see [chapter 5](#))
- using the tool "PrinterSet"
- in CUSTOM/POS emulation, by using the 0x1D 0xE7 command (for more details, refer to the commands manual)
- by driver

10.4 Printing area

In order to print ticket containing only one black mark and to not overlay printing to a black mark (that will make it useless for the next alignment), it is important to well calibrate the length of the printing area of ticket according to the inter-black mark distance.

The following figure shows an example of tickets with “Black mark distance” set to 0:



A “Non-printable area” = “Distance between cutter/printhead”

where:

”Distance between cutter/printhead” = 10.5 mm

H Distance between the first and the last print line, called “Height of the printing area”.

L Distance between an edge of the black mark and the next one, called “Inter-black mark distance”.

D Automatic feed for alignment at the next black mark.

To use all the black marks on paper, you must comply with the following equation:

$$H + A \leq L$$

The height of the printing area (H) can be increased to make no progress on alignment (D) but no further.



11 TECHNICAL SERVICE

In case of failure, contact the technical service detailing:

1. Product code
2. Serial number
3. Hardware release
4. Firmware release

To get the necessary data, proceed as follows:

1

XXXXXXXXXXXXXXXXX Rx



00000000000000000000

Write down the data printed
on the product label (see [paragraph 2.3](#)).

2

<device name>

SCODE. <code>	-	rel 1.00
FCODE. <code>	-	rel 1.00

PRINTER SETTINGS

1 «.....» 640

PRINthead WORKING GOOD!

PRINTER TYPE<device model>

PRINTING HEAD TYPE<head model>

INTERFACEUSB

PROGRAM MEMORY TEST.....OK

FW
└──┬──

Print a setup report (see [paragraph 5.1](#)).
The setup report shows
the firmware release.

3



Login to the site www.custom4u.it
and use the support tools.

CUSTOM[®]

CUSTOM S.p.A.

World Headquarters

Via Berettine, 2/B - 43010 Fontevivo, Parma ITALY

Tel. +39 0521 680111 - Fax +39 0521 610701

info@custom.biz - www.custom.biz

All rights reserved