

PrehKeyTec HospiTouch: Getting started / Erste Schritte



EN

Installation

This product does not require installation of any special drivers (Plug&Play). Standard operating system drivers USB/HID are used.

Usage:

The keyboard shows a similar handling like on notebook keyboards:

- Numeric codes are sent instead of characters, if NumLock is ON.
- The *blue* key functions have to be pressed in combination with **Fn**

Cleaning:

Please only use non-abrasive glass cleaner for cleaning the glass surface. During cleaning the keyboard + touchpad can be temporarily switched off:

Enable / Disable Cleaning function: **Fn** + **F12**

KeyClick:

By default an acoustic feedback tone is output for each key press. The volume can be altered temporarily in four steps (Off ... Max):

Decrease Volume: **Fn** + **←** Increase Volume: **Fn** + **→**

Sensitivity:

Key Sensitivity can be altered temporarily in four levels (Low ... High):

Less sensitive: **Fn** + **↓** More sensitive: **Fn** + **↑**

Above key combinations will alter settings only temporarily. When reconnecting the keyboard, original settings will be restored.

For additional help, please contact support@prehkeytec.de

DE

Installation

Dieses Produkt benötigt keine speziellen Treiber (Plug&Play). Standard-Treiber des Betriebssystems für USB/HID werden verwendet.

Bedienung:

Die Tastatur bietet ähnliche Bedienung, wie bei Notebook-Tastaturen:

- Zifferncodes statt Buchstaben, wenn NumLock eingeschaltet ist.
- Die *blauen* Funktionen erreicht man über Kombination mit **Fn**

Reinigung:

Bitte benutzen Sie zum Reinigen nur Glasreiniger ohne scheuernde Bestandteile. Die Tastatur kann zum Reinigen abgeschaltet werden:

Aktivieren/Ausschalten der Reinigungsfunktion: **Fn** + **F12**

Akustische Rückmeldung: "KeyClick":

Bei jedem Tastendruck wird ein KeyClick als Rückmeldung ausgegeben. Die Lautstärke kann über Tastenkombinationen angepasst werden:

KeyClick leiser: **Fn** + **←** KeyClick lauter: **Fn** + **→**

Empfindlichkeit:

Die Tasten-Empfindlichkeit ist in vier Stufen einstellbar. (Niedrig ... Hoch):

Unempfindlicher: **Fn** + **↓** Empfindlicher: **Fn** + **↑**

Obige Änderungen gelten nur temporär. Nach dem Abziehen / Neustart der Tastatur sind wieder die ursprünglichen Einstellungen aktiv.

Weiterführende Hilfe erhalten Sie von support@prehkeytec.de

